



Wireless Properties


- Interference / bit errors
 - More sources of corruption compared to wired
- Multipath propagation
 - Signal does not travel in a straight line
- Broadcast medium
 - All traffic to everyone
- Power trade-offs
 - Important for power constrained devices





Wireless Links: High Bit Error Rate

- Multi-path propagation
 - Electromagnetic waves reflect off objects
 - Taking many paths of different lengths
 - Causing blurring of signal at the receiver




Dealing With Bit Errors

- Wireless vs. wired links
 - Wired: most loss is due to congestion
 - Wireless: higher, time-varying bit-error rate


• Dealing with high bit-error rates

- Sender could increase transmission power
 - Requires more energy (bad for battery-powered hosts)
 - Creates more interference with other senders
- Stronger error detection and recovery
 - More powerful error detection/correction codes
 - Link-layer retransmission of corrupted frames



Wireless Links: Broadcast Limitations

- Wired broadcast links
 - E.g., Ethernet bridging, in wired LANs
 - All nodes receive transmissions from all other nodes
- Wireless broadcast: fading over distance




A and B hear each other
B and C hear each other
But, A and C do not


So, A and C are unaware of their interference at B


Example Wireless Link Technologies


• Data networks


- 802.15.1 (Bluetooth): 2.1 Mbps 10 m
- 802.11b (WiFi): 5-11 Mbps 100 m
- 802.11a and g (WiFi): 54 Mbps 100 m
- 802.11n (WiFi): 200 Mbps 100 m
- 802.16 (WiMax): 70 Mbps 10 km
- Cellular networks, outdoors
 - 2G: 56 Kbps
 - 3G: 384 Kbps
 - 3G enhanced ("4G"): 4 Mbps
 - LTE: 10-100 Mbps




























- (Y) Ethernet (Wired)
- (M) 802.11 (Wireless)
- (C) Both
- (A) Neither
- All hosts on subnet see all communication
 - (Y) Ethernet (Wired)
 - (M) 802.11 (Wireless)
 - (C) Both
 - (A) Neither

















- Expensive to build hardware that detects collisions
- So, 802.11 does collision avoidance, not detection



Virtual carrier sensing

- First exchange control frames before transmitting data
 - Sender issues "Request to Send" (RTS), incl. length of data
 - Receiver responds with "Clear to Send" (CTS)
- If sender sees CTS, transmits data (of specified length)
- If other node sees CTS, will idle for specified period
- If other node sees RTS but not CTS, free to send





Impact on Higher-Layer Protocols

- Wireless and mobility change path properties
 - Wireless: higher packet loss, not from congestion
 - Mobility: transient disruptions, and changes in RTT
- Logically, impact should be minimal ...
 - Best-effort service model remains unchanged
 - TCP and UDP can (and do) run over wireless, mobile
- But, performance definitely is affected
 - TCP treats packet loss as a sign of congestion
 - TCP tries to estimate the RTT to drive retransmissions
 - TCP does not perform well under out-of-order packets
- Internet not designed with these issues in mind


Questions

• RTS/CTS more like:


- (Y) Statistical multiplexing
- (M) Time-division multiplexing
- (C) Frequency-division multiplexing

• Which of following is NOT true?

- (Y) Collisions are minimized when RTS/CTS used.
- (M) Sender can always detect a collision without feedback from receiver.
- (C) TCP congestion control works poorly in wireless without link-layer retransmission.
- (A) Wireless generally has higher loss rates than wired.



Bluetooth: 802.15.1 "personal-area-networks"



PHY: Spread Spectrum – Frequency Hopping

- Nodes rapidly jump between frequencies
- Sender and receiver coordinated in jumps
 - How coordinate? Pseudorandom number generator, with shared input known to sender/receiver
- If randomly collide with other transmitted, only for short period before jump again
- Bluetooth
 - 79 frequencies, on each frequency for 625 microseconds
 - Each channel also uses TDMA, with each frame taking 1/3/5 consecutive slots.
 - Only master can start in odd slot, slave only in response

Infrastructure vs. Ad Hoc

• Infrastructure mode

- Wireless hosts are associated with a base station
- Traditional services provided by the connected network
- E.g., address assignment, routing, and DNS resolution

• Ad hoc networks

- Wireless hosts have no infrastructure to connect to
- Hosts themselves must provide network services

· Similar in spirit to the difference between

- Client-server communication
- Peer-to-peer communication

Conclusions

• Wireless

- Already a major way people connect to the Internet
- Gradually becoming more than just an access network

• Mobility (not discussed)

- Today's users tolerate disruptions as they move
- ... and applications try to hide the effects
- Tomorrow's users expect seamless mobility

• Challenges the design of network protocols

- Wireless breaks the abstraction of a link, and the assumption that packet loss implies congestion
- Mobility breaks association of address and location
- Higher-layer protocols don't perform as well